



S-Handle C-C	337-330
S-Handle C-N	337-331
S-Handle C-G	337-332


Instrukcja montażu  
Instructions for assembly  
Instruction de montage  
Montageanleitung  
Инструкция монтажа



S-Handle Q-C	337-320
S-Handle Q-N	337-321
S-Handle Q-G	337-322

Instrukcja montażu  
Instructions for assembly  
Instruction de montage  
Montageanleitung  
Инструкция монтажа







**VALCOMP**  
by MANTION

S-Handle R-C 337-326  
S-Handle R-N 337-327  
S-Handle R-G 337-328

Instrukcja montażu  
Instructions for assembly  
Instruction de montage  
Montageanleitung  
Инструкция монтажа





**VALCOMP**  
by MANTION

S-Handle S-C 337-323  
S-Handle S-N 337-324  
S-Handle S-G 337-325

Instrukcja montażu  
Instructions for assembly  
Instruction de montage  
Montageanleitung  
Инструкция монтажа

